



HR 46 VALVE



HR 258
INTAKE EXHAUST VALVE



HR 259
KOMATSU



HR 260
TOYOTA



HR 261
ISUZU



HR 262
NISSAN EXHAUST VALVE



HR 263
NISSAN INTAKE VALVE



HR 264
MITSUBISHI VALVE GUIDE



HR 265
KOMATSU VALVE GUIDE